

NOTE/NOTAS

- VERTICAL ACCURACY MUST SUIT THE REQUIREMENTS OF GRADE 2.
 ALL EXPOSED CORNERS MUST BE BULL NOSED 25mm
 CONSTRUCTION JOINTS: (a)REMOVE ALL FINE PARTICLES BY WASHING OFF MUTTH VICH DESSURE WATED WITH HIGH PRESSURE WATER! 1-3HOURS AFTER PLACING.
- 1-3HOURS AFTER PLACING.
 (b)KEEP CONSTANTLY WET UNTIL NEW CONCRETE IS POURED.
 4. CURING:
 AFTER THE CONCRETE IS PLACED, THE EXPOSED SURFACE SHALL BE KEPT CONSTANTLY DAMP FOR AT LEAST 10 DAYS BY SUCH METHODS AS APPROVED BY THE ENGINEER.
 SHITTEP EEPBINE IS AND TICS OF THE DECOMPOSED
- 5. SHUTTER FERRULES AND TIES SHALL BE OF THE
- THE CAST-IN TYPE, RUST RESISTANT AND WATER TIGHT. 6. FERRULES SHALL NOT BE CLOSER THAN 350mm FROM THE TOP OF CONCRETE.
- 7. TOTAL EXCAVATION MUST BE APPROVED BEFORE CONCRETE WORK COMMENCE.
- 8. ALL CONCRETE TO BE 30MPa UNLESS
- OTHERWISE SPECIFIED.
- ALL VJ COUPLINGS AND FLANGE ADAPTERS 9.
- TO BE SUPPLIED BY CIVIL CONTRACTOR. 10. CABLE SLEEVE TO BE CONTINUOUS, NO JOINTS
- WILL BE PERMITTED.
 PRIOR TO CASTING OF BLINDING OR ANY CONCRETE, ALL COMPACTED BACKFILL MUST BE TESTED WITH A DCP TO ENSURE UNIFORM COMPACTION THROUGH OUT THE COMPACTED BASE AREA OF THE STRUCTURE.
- COMPACTION TESTS MUST BE CARRIED OUT AND TEST CERTIFICATES ISSUED TO ENGINEER

© COPYRIGHT RESERVED TECROVEER 2015-00 DRAWING REMAIN THE PROPERTY OF TECROVEER UNTL FULLY PAID		
REVISION	DATE	DRAWING No.
		DWS-LNW-ECS078- GWWTW-GEN-001
		REV 0