





WETLAND ZONES SENSITIVITY RATINGS

High - Depression Wetland Core Zone

Moderate - Disturbed Outer Zone

Low - Infill Zone

Transformed - Existing Infrastructure

