

Facility Illustration(s)



Example of a typical energy breaker system at inlets.



Example of the working of an energy breaker system at a pump outlet.



Example of a stream cross protection measured that will be implemented to protect the pipeline as well as to limit possible erosion.



Example of the scour-pitching to be implemented where required. This is usually used to protect the environment from erosion and vegetation loss at drainage valves.



Example of a gabion constructed as part of a stream cross protection measures to be implemented

