

## NOTE/NOTAS

- VERTICAL ACCURACY MUST SUIT THE REQUIREMENTS OF GRADE 2.
  ALL EXPOSED CORNERS MUST BE BULL NOSED 25mm
- CONSTRUCTION JOINTS:
  (a)REMOVE ALL FINE PARTICLES BY WASHING OFF WITH HIGH PRESSURE WATER! 1-3HOURS AFTER PLACING.

(b)KEEP CONSTANTLY WET UNTIL NEW CONCRETE IS POURED.

- CURING: AFTER THE CONCRETE IS PLACED, THE EXPOSED SURFACE SHALL BE KEPT CONSTANTLY DAMP FOR AT LEAST 10 DAYS BY SUCH METHODS AS APPROVED BY THE ENGINEER.
- 5. SHUTTER FERRULES AND TIES SHALL BE OF THE CAST-IN TYPE, RUST RESISTANT AND
- CAST-IN TIPE, ROST RESISTANT AND
  WATER TIGHT.
  FERRULES SHALL NOT BE CLOSER
  THAN 350mm FROM THE TOP OF CONCRETE.
  TOTAL EXCAVATION MUST BE APPROVED
  BEFORE CONCRETE WORK COMMENCE.
  TOTAL EXCAVATION AND THE TOP OF UNITED AND AND THE TOP OF UNITED AND AND THE FORMENCE.

- 8. ALL CONCRETE TO BE 30MPa UNLESS OTHERWISE SPECIFIED.
- ALL VJ COUPLINGS AND FLANGE ADAPTERS 9.
- TO BE SUPPLIED BY CIVIL CONTRACTOR. 10. CABLE SLEEVE TO BE CONTINUOUS, NO JOINTS WILL BE PERMITTED.
- 11. PRIOR TO CASTING OF BLINDING OR ANY CONCRETE, ALL COMPACTED BACKFILL MUST BE TESTED WITH A DCP TO ENSURE UNIFORM COMPACTION THROUGH OUT THE COMPACTED BASE AREA OF THE STRUCTURE.
- 12. COMPACTION TESTS MUST BE CARRIED OUT AND TEST CERTIFICATES ISSUED TO ENGINEER

	Ç	© COPYRIGHT RESERVED TECROVEER 2015-09 DRAWING REMAIN THE PROPERTY OF TECROVEER UNTIL FOLLY PAID
REVISION	DATE	DRAWING No.
		DWS-LNW-ECS078- GWWTW-GEN-000
		REV 0

1